



WHAT YOU'LL NEED:

- Jumbo Push Pop
- Plastic Pencil Sharpener
- Sturdy Glue Or Epoxy
- Pliers
- Drill

INSTRUCTIONS:

1. After your child is done enjoying their delicious Push Pop, remove the spring with pliers.
2. Drill a pencil-sized hole in the top of the cap. Be sure to drill away from yourself and keep your hands safely out of the way.
3. Apply glue or epoxy to the edge of the pencil sharpener with a hole.
4. Stick a pencil through the Push Pop cap hole, and use this as a guide to glue in the pencil sharpener.
5. Hold the pencil sharpener firmly in place until glue/epoxy dries. For extra stability, it's recommended that you reinforce with more glue/epoxy.
6. Pop the cap back onto the Push Pop tube, and your pencil sharpener is ready to go! Now you're looking sharp!